

# AGENCY ARMS EXA PISTOL

# EXA

## OWNER'S MANUAL



# INTRODUCTION


The RWA Agency Arms EXA Pistol is the first GBB Pistol that RWA has ever released under the Agency Arms & Lone Wolf Distribution license. Most notably the pistol is modeled after the same training pistol used by Agency Arms Asset Paul Vandunk! At a glance, the EXA boasts Agency Arms' EXA Hybrid slide cut, mid-line outer barrel, and Lone Wolf's signature Timberwolf Frame.




ADJUSTABLE TRIGGER



INTERCHANGEABLE BACKSTRAP




FIBER FRONT SIGHT



SHARK SCALE © FAUX STIPPLE



AMBI-CHANGE MAGAZINE RELEASE



COMPATIBLE WITH GLOCK HOLSTERS






BLACKOUT BARREL

<b>MODEL:</b>	Agency Arms EXA
<b>TYPE:</b>	Gas Blow Back Pistol
<b>POWER SOURCE:</b>	Green Gas
<b>POWER:</b>	290 fps
<b>HOP-UP:</b>	Adjustable
<b>MAGAZINE CAPACITY:</b>	23 + 1
<b>MATERIAL:</b>	Die-Cast Aluminum, Nylon Fiber
<b>OVERALL LENGTH:</b>	195mm
<b>WEIGHT:</b>	672g

# SAFETY RULES

READ THE SAFETY RULES BEFORE HANDLING AIRSOFT GUNS




The product is suitable only for persons 18 years or older. RWA is not responsible for any accident or malfunction caused by improper handling, modification, alteration or disassembly. Please follow the instructions below during use.

## ⚠ WARNING


1. When shooting the air gun, you and all participants must wear goggles or other eye protective gear.
2. Never aim at, shoot a person or animal as the target. Always attach a protective plug to the muzzle, except when you are ready to shoot.
3. Avoid pulling the trigger carelessly.
4. Never look into the gun muzzle.
5. Never shoot when people and cars are present.
6. Store the airsoft gun out of reach of children.
7. Never disassemble or modify the gun.
8. Always direct the muzzle towards a safe direction.
9. Always put the gun in a case or bag when transporting it.
10. BB bullets may be fired even if the magazine is removed.
11. Always set the selector lever to the Safe position when you are not ready to shoot.
12. Do not place your finger inside the trigger unless you are ready to fire the gun.
13. Never use the gun in public in a threatening manner that may make others think it is a real gun. This is unlawful and dangerous.
14. If using the gun in the USA or Italy, do not display this gun in public without an orange barrel tip.

# EXPLODED VIEW 1

## ○ SLIDE




## ○ BARREL




# EXPLODED VIEW 2

## GRIP



# EXPLODED VIEW 3

## ○ MAGAZINE



# ADJUST THE HOP-UP

1. Press magazine catch



2. Remove magazine



3. Rack pistol slide once to ensure hammer is up



4. Pull slide takedown lever down on both sides and pull the slide forward off the frame



5. Adjust hop-up with hop-up wheel as desired



6. Reinstall slide back onto frame



\*Hop-Up is a mechanism in the gun which puts a slight backspin on a BB to help it travel greater distances, much like how putting backspin on a tennis ball or golf ball will help the ball stay in the air longer